
# **Drilling Machine SOP**

## • 鑽尾機之外觀



粗略分辨,鑽尾機為以下幾個部分所組成

A: 遙控控制用電腦

B: 電控板手與測試座

C: 手動控制面板

D: 機台內部電路設備

D部分非實驗室操作員的作業範圍,後續僅針對B、C部分編寫操作文件

### 1. 確認機台設置



- 確認螺絲尺寸與表面處理之種 類,此據將影響荷重、轉速與 測試時間設定值
- 2. W為放置砝碼之載座。 根據下頁table,確認確認螺絲 尺寸與相對應之軸向荷重Axial Loading 因為機台本身已有重量,進行

因為機台本身已有重量,進行 配重時要一併算入 故,配重計算公式為

Axial Loading = W + A

放置砝碼時,因單位換算之緣 故無法做到十分精準,故僅取 最接近的數值

3. G為調整轉速開關,僅有1800 RPM與2500 RPM兩種選項。 根據下頁table,確認螺絲尺寸 與相對應之轉速,機台標示1為 1800 RPM, 2為2500 RPM

#### 1. 確認機台設置 SAE J78

According to SAE J78, machine must be setup with following table:

Nominal Size	Plate Thickness* Unit: inch		Axial Loading** Unit: lb			Drilling Time*** Unit: sec
	Max	Min	Α	В	С	Offic. See
4	0.068	0.062	25	30	40	2
6	0.068	0.062	30	35	45	2.5
8	0.068	0.062	30	35	45	3
10	0.068	0.062	35	40	50	3.5
12	0.068	0.062	45	50	60	4
1/4	0.068	0.062	45	50	60	5

<sup>\*:</sup> Test plates shall be low carbon, cold rolled steel having a hardness of Rockwell B60-85.

- \*\*: Axial loads are varied to offset the detrimental effects on drilling capability created by finishes applied to screws in accordance with the following:
- A Axial loads tabulated shall apply to plain, oiled, and commercial phosphate coating and cadmium and zinc platings up to 0.0003 in thickness.
- B Axial loads tabulated shall apply special electroplated finishes exceeding 0.0003 in thickness and to special coatings, such as thread sealing hot melts, etc.
- C Axial loads tabulated shall apply to chromium finish.
- \*\*\*: Tool speed shall be 2500 rpm for screw sizes No. 4 through No. 10. Tool speed of 1800 rpm is recommended for screw sizes No. 12 and
- 1/4; however, 2500 rpm may be used provided care is exercised to minimize influence of high heat buildup due to surface speed.

## 1. 機台設置 by IFI-504

According to IFI 504, machine must be setup with following table:

Nominal Size	Plate Thickness* Unit: inch		Axial Loading** Unit: lb			Drilling Time*** Unit: sec
	Max	Min	Α	В	С	Offic. Sec
4	0.068	0.062	25	30	40	2
6	0.068	0.062	30	35	45	2.5
8	0.068	0.062	30	35	45	3
10	0.068	0.062	35	40	50	3.5
12	0.068	0.062	45	50	60	4
1/4	0.068	0.062	45	50	60	5

<sup>\*:</sup> Test plates shall be low carbon, cold rolled steel having a hardness of Rockwell B60-85.

- \*\*: Axial loads are varied to offset the detrimental effects on drilling capability created by finishes applied to screws in accordance with the following:
- A Axial loads tabulated shall apply to plain, oiled, and commercial phosphate coating and cadmium and zinc platings up to 0.0003 in thickness.
- B Axial loads tabulated shall apply special electroplated finishes exceeding 0.0003 in thickness and to special coatings, such as thread sealing hot melts, etc.
- C Axial loads tabulated shall apply to chromium finish.
- \*\*\*: Tool speed shall be 2500 rpm for screw sizes No. 4 through No. 10. Tool speed of 1800 rpm is recommended for screw sizes No. 12 and
- 1/4; however, 2500 rpm may be used provided care is exercised to minimize influence of high heat buildup due to surface speed.

## 1. 機台設置 by IFI-113

According to IFI 113, machine must be setup with following table:

Nominal Size	Plate Thickness* Unit: inch			Axial Loading** Unit: lb	Drilling Time*** Unit: sec	
	Max	Min	Α	В	С	Offic. See
4	0.068	0.062	25	30	40	2
6	0.068	0.062	30	35	45	2.5
8	0.068	0.062	30	35	45	3
10	0.068	0.062	35	40	50	3.5
12	0.068	0.062	45	50	60	4
1/4	0.068	0.062	45	50	60	5

<sup>\*:</sup> Test plates shall be low carbon, cold rolled steel having a hardness of Rockwell B60-85.

- \*\*: Axial loads are varied to offset the detrimental effects on drilling capability created by finishes applied to screws in accordance with the following:
- A Axial loads tabulated shall apply to plain, oiled, and commercial phosphate coating and cadmium and zinc platings up to 0.0003 in thickness.
- B Axial loads tabulated shall apply special electroplated finishes exceeding 0.0003 in thickness and to special coatings, such as thread sealing hot melts, etc.
- C Axial loads tabulated shall apply to chromium finish.
- \*\*\*: Tool speed shall be 2500 rpm for screw sizes No. 4 through No. 10. Tool speed of 1800 rpm is recommended for screw sizes No. 12 and
- 1/4; however, 2500 rpm may be used provided care is exercised to minimize influence of high heat buildup due to surface speed.